



How To Apply Ames' Rubber Stucco™ with Wagner Power Tex Texture Sprayer

Preparation

Attach the air turbine to the sprayer. Select the hopper position and select the nozzle for the desired texture. Refer to the sprayer application instructions for more information.

Stir the coating and add it to sprayer hopper. Before starting your project, test spray to be sure you are happy with the results.



Prepare the area to be coated. Seal cracks and joints with Blue Max trowel-grade. Mask off areas to protect from overspray. Apply a primer coat of Blue Max or Super Primer to increase adhesion to the surface if needed. Blue Max may be applied with the Power Tex texture sprayer, or similar sprayer. It may also be brush or roller applied.



Application

Spray the coating evenly onto the surface. Apply one to three coats of Ames' Rubber Stucco Coating to the surface. More coats equals longer life.

Clean up.

Ames coatings clean easily with water. Empty the hopper. Remove the air turbine. Rinse the spray head and hopper

